
# ergotron®

#### Interactive Arm VHD




© 2013 Ergotron, Inc. rev. 10/07/2019 DIM-interactVHD Content is subject to change without notification


Americas Sales and Corporate Headquarter	EMEA Sales	APAC Sales	Worldwide OEM Sales
St. Paul, MN USA (800) 888-8458 +1-651-681-7600 www.ergotron.com sales@ergotron.com	Amersfoort, The Netherlands +3133 45 45 600 www.ergotron.com info.eu@ergotron.com	Tokyo, Japan www.ergotron.com apaccustomerservice@ergotron.com	www.ergotron.com info.oem@ergotron.com

## ergotron®

#### Interactive Arm VHD







© 2013 Ergotron, Inc. rev. 10/07/2019 DIM-interactVHD Content is subject to change without notification


Americas Sales and **Worldwide OEM Sales Corporate Headquarter EMEA Sales APAC Sales** St. Paul, MN USA Amersfoort, The Netherlands www.ergotron.com Tokyo, Japan (800) 888-8458 +31 33 45 45 600 info.oem@ergotron.com www.ergotron.com +1-651-681-7600 www.ergotron.com apaccustomerservice@ergotron.com www.ergotron.com info.eu@ergotron.com sales@ergotron.com

### ergotron®


#### **Mounting Height for Ergonomic Workstation**


This mounting height is a recommendation for an ergonomic workstation that accommodates user heights of 5'0"-6'1" (152-185cm) when set up for standing and user heights of 5'0"-6'4" (152-193cm) when set up for sitting.

If user heights are different than this, you should change mounting height to accommodate user heights. (Change mounting height one inch for every one inch difference in user heights).



Mounting height assumes there is a 6" (152 mm) distance between the center of your monitor mounting holes and the top of the screen. If your distance is smaller, you should increase mounting height accordingly, if your distance is larger, you should decrease your mounting height accordingly.





© 2013 Ergotron, Inc. rev. 10/07/2019 DIM-interactVHD Content is subject to change without notification

Americas Sales and Corporate Headquarter	EMEA Sales	APAC Sales	Worldwide OEM Sales
St. Paul, MN USA (800) 888-8458 +1-651-681-7600 www.ergotron.com sales@ergotron.com	Amersfoort, The Netherlands +3133 45 45 600 www.ergotron.com info.eu@ergotron.com	Tokyo, Japan www.ergotron.com apaccustomerservice@ergotron.com	www.ergotron.com info.oem@ergotron.com